

INSTRUCTION MANUAL 1.1-DICHLOROETHANE DETECTOR TUBE

No.235SA

- ★ READ CAREFULLY THIS INSTRUCTION MANUAL AND THE INSTRUCTIONS OF THE ASPIRATING PUMP PRIOR TO USING THIS PRODUCT.
- ★ DO NOT DISCARD THIS INSTRUCTION MANUAL UNTIL ALL THE TUBES IN THIS BOX ARE USED UP.

1. PERFORMANCE:

Measuring Range	: 10 - 160 ppm
and Pump Stroke	: 1 (100 mL)
Sampling Time	: 2 minutes
Colour Change	: White → Purple
Detectable Limit	: 3 ppm
Operating Temperature	: 0 - 40 °C (32 - 104°F) (Temperature correction is necessary.)
Operating Humidity	: 20 - 80 %R.H. (No correction is necessary.)
Aspirating Pump	: Model AP-20, AP-20S, 400B, AP-1, AP-1S or 400A

ACAUTION

- 1. THE DETECTOR TUBE AND PRETREAT TUBES CONTAIN CHEMICAL REAGENTS.
- 2. DO NOT TOUCH THESE REAGENTS DIRECTLY ONCE TUBES WERE BROKEN.
- 3. KEEP THE TUBES OUT OF THE REACH OF CHILDREN.

NOTICE

- USE ONLY WITH PUMP MODELS AP-20, AP-20S, 400B, AP-1, AP-1S OR 400A. OTHERWISE, CONSIDERABLE ERROR IN INDICATION MAY OCCUR.
- 2. BEFORE TESTING, CHECK THE ASPIRATING PUMP FOR LEAKS (REFER TO ITEM 8. INSPECTION OF ASPIRATING PUMP). ANY PUMPS SHOWING SIGNS OF LEAKAGE SHOULD BE CORRECTED BEFORE USE.
- 3, DO NOT USE THIS TUBE OUTSIDE THE STATED OPERATING TEMPERATURE RANGE
- 4. STORE TUBES IN A REFRIGERATED PLACE 0 10 °C (32 50°F), AND USE BEFORE EXPIRATION DATE PRINTED ON THE TOP OF THE BOX.
- 5. PRIOR TO USE, READ CAREFULLY ITEM 9, USER RESPONSIBILITY.
- 6. READ THE CONCENTRATION IMMEDIATELY AFTER MEASUREMENT.
- 7. THE COLOUR OF CONNECTING TUBE WILL CHANGE TO BLACK AFTER MEASUREMENT, BUT IT DOES NOT AFFECT THE READINGS.

2. SAMPLING AND MEASUREMENT:




Fig.1

① Break both ends of the detector tube and pretreat tubes (Type 1, Type 2), and connect each end of the detector tube and pretreat tubes with connecting tube as shown in Fig.1.

▲ CAUTION SAFETY GLASSES AND GLOVES SHOULD BE WORN TO PREVENT INJURY FROM SPLINTERING GLASS.

- 2 Insert the detector tube into the aspirating pump securely as showin in Fig. 1. (Arrow marks on the detector tube and pretreat tubes shall point to the pump.)
- 3 Align the guide marks on the shaft and stopper of the aspirating pump.
- 4 Pull the pump handle at a full stroke until it locks and wait for 2 minutes or until the completion of sampling is confirmed with the flow indicator of the pump (See descriptions about the flow indicator in the instruction manual of the pump).
- ⑤ On completion of sampling, read the scale at the maximum point of the stained layer.

- SPECIAL NOTE: I. The scale is calibrated at 20 °C (68°F), 50 %R.H. and 1013 hPa. Readings obtained in other circumstances should be corrected (REFER TO ITEM 3. CORRECTION FOR AMBIENT CONDITIONS).
 - II. When the maximum point of the stained layer is unclear or oblique, read the scale at the centre between the longest and shortest points.

3. CORRECTION FOR AMBIENT CONDITIONS:

① Temperature; Correct the tube reading by following temperature correction table.

Temperature Correction Table							
Tube	Corrected Concentration (ppm)						
Readings	0°C	10℃	20 ℃	30 ℃	40 °C		
(ppm)	(32°F)	(50°F)	(68°F)	(86°F)	(104°F)		
160	230	195	160	118	75		
140	200	170	140	105	70		
120	170	145	120	90	60		
100	140	120	100	75	50		
80	110	95	80	60	40		
60	80	70	60	48	35		
40	50	45	40	33	25		
20	25	23	20	18	15		
10	10	10	10	10	10		

② Humidity; No correction is necessary.

3 Atmospheric Pressure; True concentration = Tube reading ×

Atmospheric pressure (in hPa)

4. INTERFERENCES:

Nitric oxides, Halogens or Halogenated hydrocarbons produce a similar stain and give higher readings. Coexistence of more than 400 ppm Alcohols, more than 20 ppm Hexane or more than 20 ppm Toluene give lower readings.

5. CHEMICAL REACTION IN THE DETECTOR TUBE:

CH₃CHCl₂ + CrO₅ + H₂S₂O₇ → Cl₂

6. DISPOSAL OF TUBES:

USED TUBES SHOULD BE DISPOSED CAREFULLY ACCORDING TO RELEVANT REGULATIONS, IF ANY.

7. HAZARDOUS AND DANGEROUS PROPERTIES OF 1.1-DICHLOROETHANE:

TLV-TWA ◆

100 ppm

Explosion range in air

5.6 - 11.4 %

◆ Threshold Limit Value established by the American Conference of Governmental Industrial Hygienists, 2008.

8. INSPECTION OF ASPIRATING PUMP:

Checking for leaks:

- ① Insert a sealed, unbroken detector tube into the pump.
- ② Align the guide marks on the shaft and stopper of the pump.
- 3 Pull the handle to a full stroke and wait for 1 minute.
- 4 Unlock the handle and allow it to return slowly into the pump by holding the cylinder and handle securely. ACAUTION HANDLE WILL TEND TO SNAP BACK INTO THE PUMP QUICKLY.
- (5) If the handle returns completely to the original position, the performance is satisfactory. Otherwise, refer to maintenance procedures shown in the instruction manual of the pump to correct the leakage.

9. USER RESPONSIBILITY:

It is the sole responsibility of the user of this equipment to ensure that the equipment is operated, maintained, and repaired in strict accordance with these instructions and the instructions provided with each Model AP-20, AP-20S, 400B, AP-1, AP-1S or 400A aspirating pump, and that detector tubes are not used which are either beyond their expiration date or have a colour change different to that stated in the Performance specifications.

The Manufacturer and Manufacturer's Distributors shall not be otherwise liable for any incorrect measurement or any damages, whether damages result from negligence or otherwise.

IME2351/1



Printed in Japan