

## INSTRUCTION MANUAL ANILINE DETECTOR TUBE

No.181S

★ READ CAREFULLY THIS INSTRUCTION MANUAL AND THE INSTRUCTIONS OF THE ASPIRATING PUMP PRIOR TO USING THIS PRODUCT.

★ DO NOT DISCARD THIS INSTRUCTION MANUAL UNTIL ALL THE TUBES IN THIS BOX ARE USED

## 1. PERFORMANCE:

and Pump Stroke : 2 pump strokes 1 pump stroke  (*) Graduations on the detector tube are based on 1 pump stroke.	Measuring Range	: 1 - 15 ppm	2 - 30 ppm (*)	
(*) Graduations on the detector tube are based on 1 pump stroke.	and Pump Stroke	2 pump strokes	1 nump stroke	
	(*) Graduations on th	e detector tube are based of	on 1 pump stroke	
Sampling 1 ime ; 1 minute 30 seconds	Sampling Time	: 1 minute		
Colour Change : White → Yellow		: White → Yellow		
Detectable Limit : 0.05 ppm (2 pump strokes)	Detectable Limit	: 0.05 ppm (2 pump s	trokes)	
Operating Temperature : 0 - 40 °C (32 - 104°F) (No correction is necessary)		: 0 - 40 °C (32 - 104	°F) (No correction is necessary)	<del></del> .
Aspirating Pump : Model AP-20, AP-20S, 400B, AP-1, AP-1S or 400A	Aspirating Pump	: Model AP-20, AP-29	OS, 400B, AP-1, AP-1S or 400A	

#### A CAUTION

- 1. THE DETECTOR TUBE CONTAINS CHEMICAL REAGENTS.
- 2. DO NOT TOUCH THESE REAGENTS DIRECTLY ONCE TUBES WERE BROKEN. 3. KEEP THE TUBES OUT OF THE REACH OF CHILDREN.

#### NOTICE

- I. USE ONLY WITH PUMP MODELS AP-20, AP-20S, 400B, AP-1, AP-1S OR 400A. OTHERWISE, CONSIDERABLE ERROR IN INDICATION MAY OCCUR.
- 2. BEFORE TESTING, CHECK THE ASPIRATING PUMP FOR LEAKS (REFER TO ITEM 8. INSPECTION OF ASPIRATING PUMP). ANY PUMPS SHOWING SIGNS OF LEAKAGE SHOULD BE CORRECTED BEFORE USE.
- 3. DO NOT USE THIS TUBE OUTSIDE THE STATED OPERATING TEMPERATURE RANGE.
- 4. STORE TUBES IN A COOL AND DARK PLACE (0-25 °C/32-77°F), AND USE BEFORE EXPIRATION DATE PRINTED ON THE TOP OF THE BOX.
- 5. PRIOR TO USE, READ CAREFULLY ITEM 9 USER RESPONSIBILITY
- 6. READ THE CONCENTRATION IMMEDIATELY AFTER MEASUREMENT.

### 2. SAMPLING AND MEASUREMENT:




Fig.1

① Break both ends of the detector tube.

#### SAFETY GLASSES AND GLOVES SHOULD BE WORN TO PREVENT INJURY A CAUTION FROM SPLINTERING GLASS.

② Insert the detector tube into the aspirating pump securely as shown in Fig.1. (Arrow mark shall point to the pump.)

3 Align the guide marks on the shaft and stopper of the aspirating pump.

Pull the pump handle at a full stroke until it locks and wait for 30 seconds or until the completion of sampling is confirmed with the flow indicator of the pump (See descriptions about the flow indicator in the instruction manual of the pump).

⑤ On completion of sampling, read the scale at the maximum point of the stained layer.

When the concentration is below the scale range, 2 pump strokes can be used to determine concentrations of 1 to 15 ppm. Then multiply the reading value by 1/2.

- SPECIAL NOTE: I. The scale is calibrated at 20 °C (68°F), 50 %R.H. and 1013hPa, Readings obtained in other circumstances should be corrected (REFER TO ITEM 3. CORRECTION FOR AMBIENT CONDITIONS).
  - II. When the maximum point of the stained layer is unclear or oblique, read the scale at the centre between the longest and shortest points.

## 3. CORRECTION FOR AMBIENT CONDITIONS:

Temperature, No correction is necessary.

② Humidity; No correction is necessary.

3 Atmospheric Pressure; True concentration = Tube reading × Atmospheric pressure (in hPa)

#### 4. INTERFERENCE:

Toluidine produce a similar stain. Coexistence of Toluidine of concentration more than a one-third of Aniline gives higher readings. Coexistence of Ammonia of concentration more than the same with Aniline gives higher readings. Aliphatic or Aromatic amine give higher readings.

# 5. CHEMICAL REACTION IN THE DETECTOR TUBE:

By reacting with p-Dimethylamio-benzaldehyde, Azomethine is produced.

$$NH_2 + CHO - N(CH_3)_2 - NCH_3)_2 + H_2(CH_3)_2 + H_3(CH_3)_2 + H_3(CH$$

### 6. DISPOSAL OF TUBES:

USED TUBES SHOULD BE DISPOSED CAREFULLY ACCORDING TO RELEVANT REGULATIONS,

## 7. HAZARDOUS AND DANGEROUS PROPERTIES OF ANILINE:

TLV-TWA ◆ : 2 ppm

Explosion range in air  $1.3 \sim 11 \%$ 

◆ Threshold Limit Value established by the American Conference of Governmental Industrial Hygienists, 2008.

### 8. INSPECTION OF ASPIRATING PUMP:

Checking for leaks:

- (1) Insert a sealed, unbroken detector tube into the pump.
- Align the guide marks on the shaft and stopper of the pump.
- 3 Pull the handle to a full stroke and wait for 1 minute.
- 4 Unlock the handle and allow it to return slowly into the pump with holding the cylinder and handle securely. ACAUTION HANDLE WILL TEND TO SNAP BACK INTO THE PUMP QUICKLY.
- (5) If the handle returns completely to the original position, the performance is satisfactory. Otherwise, refer to maintenance procedures shown in the instruction manual of the pump to correct the leakage,

### 9. USER RESPONSIBILITY:

It is the sole responsibility of the user of this equipment to ensure that the equipment is operated, maintained, and repaired in strict accordance with these instructions and the instructions provided with each Model AP-20, AP-20S, 400B, AP-1, AP-1S or 400A aspirating pump, and that detector tubes are not used which are either beyond their expiration date or have a colour change different to that stated in the Performance specifications.

The Manufacturer and Manufacturer's Distributors shall not be otherwise liable for any incorrect measurement or any damages, whether damages result from negligence or otherwise.

IME1810

Printed in Japan