

INSTRUCTION MANUAL VINYL CHLORIDE DETECTOR TUBES

No.132SB

igstar read carefully this instruction manual and the instructions of the ASPIRATING PUMP PRIOR TO USING THIS PRODUCT.

igstar do not discard this instruction manual until all the tubes in this box are USED UP.

1. PERFORMANCE:


Measuring Range	: 5 - 500 ppm	
and Sampling Time	: 1.5 minutes	
Number of Pump Stroke	: 1 (100mL)	
Colour Change	: White → Reddish orange	
Detectable Limit	: 2 ppm	
Operating temperature	: 0 - 40 °C (32-104°F) (Temperature correction is necessary.)	
Aspirating Pump	: Model AP-20, AP-20S, 400A, AP-1, AP-1S or 400A	

ACAUTION

- 1. DETECTOR TUBE CONTAINS REAGENTS.
- 2. PRETREAT TUBE CONTAINS REAGENTS (READ).
- 3. DO NOT TOUCH THESE REAGENTS DIRECTLY ONCE TUBES ARE BROKEN.
- 4. KEEP THE TUBES OUT OF THE REACH OF CHILDREN

- USE ONLY WITH PUMP MODELS AP-20, AP-20S, 400B, AP-1, AP-1S OR 400A. OTHERWISE, CONSIDERABLE ERROR IN INDICATION MAY OCCUR.
- 2. BEFORE TESTING, CHECK THE ASPIRATING PUMP FOR LEAKS (REFER TO ITEM 8. INSPECTION OF ASPIRATING PUMP). ANY PUMPS SHOWING SIGNS OF LEAKAGE SHOULD BE CORRECTED BEFORE USE.
- 3. DO NOT USE THIS TUBE OUTSIDE THE STATED OPERATING TEMPERATURE RANGE.
- 4. STORE TUBES IN A DARK AND REFRIGERATED PLACE NOT TO EXCEED 10 $^{\circ}\mathrm{C}$ (50°F), AND USE BEFORE EXPIRATION DATE PRINTED ON TOP OF THE BOX.
- 5. PRIOR TO USE, READ CAREFULLY ITEM 9. USER RESPONSIBILITY.
- 6. READ THE CONCENTRATION IMMEDIATELY AFTER MEASUREMENT.

2. SAMPLING AND MEASUREMENT:



1 Break both ends of detector tube and pretreat tube, and connect each end of the detector tube and pretreat tube with rubber tube connector as shown in Fig.1

ACAUTION SAFETY GLASSES AND GLOVES SHOULD BE WORN TO PREVENT INJURY FROM SPLINTERING GLASS.

2 Insert the detector tube into aspirating pump securely as shown in Fig.1 (Arrow mark shall point to the pump)

Align the guide marks on the shaft and stopper of the aspirating pump.

4 Pull the pump handle at full stroke until it locks and wait for 1.5 minutes or until the completion of sampling is confirmed with the flow indicator of the pump (See descriptions about the flow indicator in the instructions of the pump).

⑤ On completion of sampling, read the scale at the maximum point of the stained layer.

SPECIAL NOTE: I. The scale is calibrated at 20 °C (68°F), 50 %R.H. and 1013hPa. Readings obtained in other circumstances should be corrected (REFER TO ITEM 3 CORRECTION FOR AMBIENT CONDITIONS).

II. When the maximum of the stained layer is unclear or obliquely, read the scale at the centre between the longest and shortest points.

3. CORRECTION FOR AMBIENT CONDITIONS:

① Temperature; Correct the tube reading by following temperature correction table

1		Тот			COLLEC	chon rante	4	
70 1		remp	erature Co	rrection T	able			
Tube	Corrected Concentration (ppm)							
Readings	0 ℃	- 5 °C	10 °C	15 °C	20°C	30 °C	40.80	
(ppm)	(32°F)	(41°F)	(50°F)	(59°F)	(68°F)	(86°F)	1 40 C	
500			820	600	500	430	(104°F)	
400		850	610	470	400	340	400 310	
300	-	640	440	350	300	250	230	
200	750	400	300	230	200	160	140	
100	340	200	150	120	100	80	70	
50	150	100	70	. 60	50	40	30	
20	50	40	30	25	20	15	10	
10	25	20	15	12	10	- 8	6	
	15	10	8	5]	5	5	- 5	

② Humidity; No correction is necessary.

3 Atmospheric Pressure :

True concentration = Temperature corrected × concentration Atmospheric pressure (in hPa)

4. INTERFERENCES.

Hydrogen Chloride, Chlorine and other Halogens, other Halogenated hydrocarbons produce a similar stain and will give higher reading.

5. CHEMICAL REACTION IN THE DET

CH₂=CHCl+PbO₂ → Cl₂

6. DISPOSAL OF TUBE:

USED TUBES SHOULD BE DISPOSED CAREFULLY ACCORDING TO RELEVANT REGULATIONS, IF ANY.

7. HAZARDOUS AND DANGEROUS PROPERTIES OF VINYL CHLORIDE:

TLV-TWA ◆

Explosive range in air : 3.6 - 33 %

◆ Threshold Limit Value established by American Conference of Governmental Industrial Hygienists 2004.

8. INSPECTION OF ASPIRATING PUMP:

Checking for leaks:

- ① Insert sealed, unbroken detector tube into the pump.
- Align the guide marks on the shaft and stopper of the pump.

Pull the handle to full stroke and wait for I minute.

Unlock the handle and allow it to return slowly into the pump by holding the cylinder and handle

ACAUTION HANDLE WILL TEND TO SNAP BACK INTO THE PUMP QUICKLY.

(5) If the handle returns completely to the original position, the performance is satisfactory. Otherwise, refer to maintenance procedure in the pump instructions to correct the fault.

9. USER RESPONSIBILITY:

It is the sole responsibility of the user of this equipment to ensure that the equipment is operated, maintained, and repaired in strict accordance with these instructions and the instructions provided with each Model AP-20, AP-20S, 400B, AP-1, AP-1S or 400A aspirating pump, and that detector tubes are not used which are either beyond their expiration date or have a colour change different to that stated in the Performance specifications.

The Manufacturer and Manufacturer's Distributors shall not be otherwise liable for any incorrect measurement or any damages, whether damages result from negligence or otherwise.

IME1321

Printed in Japan